

Elite

DOUBLESIDE ROLL SCREEN 24008029



Parts and accessories

1. Aluminum Base
2. Three Extension Tubes interlaced with rubber bands
3. Top Side Rod with adhesive tape
4. Lateral Security Clip

Nota: Follow the same steps to insert image on the opposite side.

The size of the banner should be 33" width up to a maximum of 78" height. A smaller measurement can be obtained by shortening the rods to desired size.


It is not recommended to use PVC substrates over 10oz.

In order to change the image, extend the image inserting the security clip allowing the image to slide until you have reached the inserting point. Once the clip has been inserted, remove the image and replace it.


Assemble Instruction




1. Turn around Base (1) placing the top side face down. Attach the image over the black line with tape on both sides (back and front). Place the superior side of the image on the Rod with tape (3).



3. Remove the lateral clip (4). Caution, removing the clip will activate the internal mechanism which will force the image into the Base (1). Hold tight the image on its superior side allowing image to flow into the base.



5. Hook the Superior Rod (3) on the Extension Tube (2)



2. Turn the Base (1) to its original position.



4. Place Extension Tubes (2) at the center of the Base (1) and pull out the image until it has reached its top.